



RX7 Receiver

Changing the headphone lead

To change the headphone lead, insert a small (4mm) screwdriver into the rectangular hole between the end of the headphone lead plastic connector moulding and the receiver body. Twist the screwdriver and the plastic insert will slide out of the receiver body.

To fit the new headphone lead slide the connector moulding into the receiver body taking care not to bend the metal pins of the connector which are attached to the circuit board.

